

Table A1: The water efficiency calculator

		(1)	(2)	(3)	(4)
Installation type	Unit of measure	Capacity/ flow rate	Use factor	Fixed use (litres/ person/ day)	Litres/ person/day = [(1) × (2)] + (3)
WC (single flush)	Flush volume (litres)	0	4.42	0.00	0.00
WC (dual flush)	Full flush volume (litres)	4	1.46	0.00	5.84
	Part flush volume (litres)	2.5	2.96	0.00	7.40
WCs (multiple fittings)	Average effective flushing volume (litres)	0	4.42	0.00	0.00
Taps (excluding kitchen/utility room taps)	Flow rate (litres/minute)	5	1.58	1.58	9.48
Bath (where shower also present)	Capacity to overflow (litres)	111	0.11	0.00	12.21
Shower (where bath also present)	Flow rate (litres/minute)	6	4.37	0.00	26.22
Bath only	Capacity to overflow (litres)	0	0.50	0.00	0.00
Shower only	Flow rate (litres/minute)	0	5.60	0.00	0.00
Kitchen/utility room sink taps	Flow rate (litres/minute)	6	0.44	10.36	13.00
Washing machine	Litres/kg dry load	6	2.1	0.00	12.60
Dishwasher	Litres/place setting	1.25	3.6	0.00	4.50
Waste disposal unit	Litres/use	If present = 1 If absent = 0	3.08	0.00	3.08
Water softener 	Litres/person/day	0	1.00	0.00	0.00
	(5)	Total calculated use = (Sum column 4)			94.33
	(6)	Contribution from greywater (litres/person/day) from Table 4.6			0
	(7)	Contribution from rainwater (litres/person/day) from Table 5.5			0
	(8)	Normalisation factor			0.91
	(9)	Total water consumption = [(5) – (6) – (7)] × (8)			85.84
	(10)	External water use			5.0
	(11)	Total water consumption = (9) + (10) (litres/person/day)			90.84

Consumption from multiple fittings

A8 Where terminal fittings with varying flow rates and capacities are specified (e.g. hot and cold taps with different flow rates, two types of shower etc.), the average consumption should be calculated as set out in Tables A2.1 to A2.7:

- Enter the full flow rate or volume of each type of fitting into column (a) of the relevant table.
- For taps, where there are separate hot and cold water taps, the flow rate of each tap should be entered separately as two tap types to calculate the average flow rate.
- Calculate the total consumption per fitting type.
- Calculate the average flow rate/volume of the fittings detailed.

e) Enter the flow rate/volume of the fitting with the highest flow rate/volume into box (f) with the exception of WCs, where this step is not relevant.

f) Calculate the proportionate flow rate/volume by multiplying the highest flow rate/volume by a factor of 0.7 with the exception of WCs, where this step is not relevant.

A9 Where the average flow rate/volume is lower than the proportionate flow rate/volume, the proportionate figure must be entered into Table A1. The proportionate figure limits the flow rate/volume that can be specified to a proportion equal to 70 per cent of the highest flow rate/volume. This reduces the benefit of specifying ultra low fittings to bring the average flow rate/volume down, where such ultra low fittings may not be acceptable to dwellings occupants.