




#### Stonework:

Rake out the open joints and fill with a mixture of lime putty and stone dust. Brush the surface to expose the aggregate. Soft and waste areas to be either cut out and matching pieces let in using the mortar, above. Alternatively, the wasted areas to be cut back to solid stone and a plastic repair undertaken using s/steel wire drilled and epoxy glued-in and a mix of slaked lime and stone dust tooled on and tooled to match existing profiles.

#### Description

Chilmark stone mullioned window with matching, moulded transom.

Moulding is ovolo with fillets. There are some open joints between components. The sills and transome have weathered resulting in a loss of profiles.

Glazing is hand-blown cylinder glass. There is one, upper pane cut with a circular vent. Glass quarries are fixed using a mixture of linseed oil putty and/or a soft lime mortar.

There are 2 metal, side-hung casements with wrought iron, spring casement stays.

Joinery: There are upper and lower sets of paneled and plain board shutters in shutter boxes.


#### Schedule of works

Remove the pane with the hole. Clean out the rebates. Replace using matching cylinder glass set in soft lime mortar.

Remove the casements, sprung stays and frames. De-rust the metal components. Paint with an epoxy-based primer and give 2 coats of Zinser oil-based paint in off-white. Replace the casements in a soft lime mortar.

Shutters are to be eased, including some paint removal. They are to be made to open and close, as intended.

Fixing putty and mortar pointing to be replaced where cracked or loose, to match existing.



Detail Specifications for repair works to:  
Window W.01/G.01

1306.D.33