

Assembly Instructions

8' x 6'6" x 4' – Apex Shed

List of parts in fixings pack

- 1 x Roll of Felt (10m for 8'x6') (5m for 6'x4')**
- 12 x 40mm Galvanised Nails**
- 48 x 70mm Green Screws**
- 26 x 50mm Green Screws**
- 12 x 30mm Wire Nails**
- 1 x Perspex Panel**
- 100 x 15mm Felt Nails**
- 14 x 60 mm Screws**

PLEASE NOTE THERE MAY BE MORE SCREWS THAN REQUIRED



With all buildings, it is important to provide a firm level base before assembling your shed. If a concrete base is being used we recommend this does not extend beyond the dimensions of the shed to stop water falling from the roof and collecting on the concrete base.



1. Place the floor section on the base you have prepared and fix the back panel to one side panel screwing through the vertical battens of the back panel into the battens on the side panel using three screws. Repeat when fitting the other side panel.

2. Fix the front panel (with door) to the two side panels as in part 1 using screws provided. After all the panels are fitted together, make sure it is all square and the cladding overlaps the floor.



3. Place one roof panel on to the top of the shed. The batten will fit into a central recess on the front and rear panels. Repeat for the other panel. Then screw into place using seven screws into each roof panel. Once the roof is screwed into place, fix the panels to the floor section. Use three screws for each side panel and two screws each for the front and back panels.

Hutton Garden and Landscaping Products

Church Lane, Northwood Green, Westbury-on-Severn, Gloucestershire GL14 1ND www.svw2000.co.uk/hutton

Tel: 01452 762089

office@hutton-ltd.co.uk