



4. Fit the long fillet in the gap between the two roof panels as shown in the photo.

5. Fix on the four corner strips with three 40mm nails in each.

6. Measure the length of the roof panel and add 100mm for cutting the lengths of felt. Once the felt is cut lay the pieces to overhang the side of the roof by at least 50mm. For an 8'x6' Apex Shed lay the third piece of felt along the centre of the roof to overhang the other two pieces (Only applies to the 8x6 Apex Shed).



7. Nail the felt around the outside of the roof every 100mm.



8. Place the Perspex panel into the window frame using a suitable sealant, then nail the 20mm x 20mm interior beading strips into place starting with the bottom strip. For added protection we recommend using a clear silicone seal around the edge of the Perspex.

9. Fit fascia pieces into place with two screws in each to front and rear of shed.

Please read carefully

Your shed has been pressure preservative treated, which is designed to prevent rot and insect attack for up to 15 years and to give softwood construction and landscaping timber products an extended and low maintenance service life. The treatment is not intended to perform as a waterproofing agent.

When using pressure treated cladding timbers in the construction of sheds or garden buildings the following guidelines should be followed to help prevent any water ingress:

1. The Timber Research and Development Association (TRADA) recommends a 16-19mm nominal thickness for cladding timbers, this shed has a nominal cladding thickness of 19mm.
2. Fixings should only be driven marginally below the surface of the cladding timbers.
3. A suitable airflow should be allowed throughout the structure to assist on-going drying, during which it is perfectly normal for some shrinkage of the cladding timbers to occur.
4. The dry, external timbers can have a water ingress protection added with the application of an appropriate and well maintained water repellent coating. This would involve a proprietary water repellent coating product which could be applied to the dry external timbers following the relevant manufacturer's guidelines. Recommended products include Thompson's WaterSeal, Hickson Decor Wax Coat and RESTOL Wood Oil.
5. For added protection and waterproofing we recommend using a clear silicone seal around the edge of the Perspex & corners before fixing on the corner strips

Hutton Garden and Landscaping Products

Church Lane, Northwood Green, Westbury-on-Severn, Gloucestershire GL14 1ND www.svw2000.co.uk/hutton

Tel: 01452 762089

office@hutton-ltd.co.uk