

Tree protection - 26078-TPP-02

Location of trees, categorisation & protection/management proposals

Aldbury House, Tunnel Hill, Alderbury, Salisbury, SP5 3DW

Scale @ A1 1:250

0510152025 m

Provided drawings

Topo and Layout: (22nd June 2026) Alderbury House 33-L-P

Tree types

G = group, T = tree

Application boundary

A

TX

BS category B Trees of moderate quality

TX

C

BS category C Trees of low quality

Protected trees

Protected trees

TX

Trees to be removed

Proposed layout

Protective barrier/fencing

Construction exclusion zone

Root protection area (RPA) boundaries for category A and B trees

Root protection area (RPA) boundaries for category C trees

Tree	Species	Category	Nominal RPA radius (m)	Tree works
G1	Scots pine	B	5.4	
T2	Horse chestnut	C	14.1	
T3	Horse chestnut	B	7.2	
T4	Horse chestnut	C	11.7	
T5	Horse chestnut	B	8.1	
T6	Horse chestnut	C	9.6	
T7	Common lime	C	12.3	Fell for development
T8	Yew	C	4.2	
T9	Lime	B	8.4	
T10	Beech	B	6.6	
T11	Sweet chestnut	B	6.6	
G12	Laurel	C	1.8	Fell part
T13	Pear	C	2.7	Fell for development
T14	Apple	C	4.8	
T15	Apple	C	3.9	
T16	Damson	C	2.1	Fell for development
T17	Apple	C	2.7	Fell for development
T18	Apple	C	3.6	

All retained trees

Carry out safety check and lift over site to 3-4 m as necessary

Trees not shown on original topographical survey

G12

How to use this plan

More detailed guidance on each Site Guidance Note (SGN) can be found in a printed hard copy compilation of all the SGNs, Manual for Managing Trees On Development Sites version 3.0, issued to the Site Manager at the pre-commencement site meeting (Note: This should be retained on site throughout the duration of works). Additionally, an electronic pdf compilation of all the SGNs, was submitted with this drawing to the local planning authority and the client. Alternatively, a pdf of each SGN can be downloaded by:

1. clicking the image links in the electronic pdf version of this plan;

2. holding a mobile phone QR (Quick Response) code reader over the QR code in the paper version of this plan; or;

3. visiting our website at <https://www.barrelltreecare.co.uk/resources/technical>;

b

barrell

TREE CONSULTANCY

Permission is granted to scale from this drawing for Local Authority Planning Approval purposes relating to tree protection measures only. Where applicable this drawing is to be read in conjunction with the arboricultural report.

www.barrelltreecare.co.uk

© Barrell Tree Consultancy

SGN 1 Monitoring tree protection

b

Always:

have a pre-commencement meeting with the tree consultant before development starts

use the tree consultant to regularly check that protection remains fit for purpose

use the tree consultant to supervise work in RPAs

keep a written record of supervision

SGN 2 Fencing protected trees

b

Always:

install protection before development starts

make sure protection is fit for purpose, i.e. it prevents damage to trees and soil

keep protection in place until there is no risk to trees

get written permission to move or remove any protection

SGN 4 Pollution control

b

Always:

keep toxic products away from RPAs

SGN 10 Installing structures in RPAs

b

Always:

use the tree consultant to supervise work in RPAs

hand-dig pile, post, or post locations down to at least 60cm

protect RPAs from contamination from poured wet concrete

SGN 11 Installing services in RPAs

b

Always:

use the tree consultant to supervise work in RPAs

select the least damaging option when installing services, so prioritise trenchless, over broken trench over continuous trench

hand-dig trenches if trenchless is not feasible

SGN 12 Landscaping in RPAs

b

Always:

use the tree consultant to supervise work in RPAs

avoid raising ground levels within 1m of the trunks of retained trees